



BUSINESS IDEAS UNLIMITED PTY LTD (B.I.U.)
Trading as Zelanga Steel
27 Northern Road,
West Heidelberg, VIC 3081
Tel (03) 9459 8802
Fax (03) 9459 5783
ABN 11 097 555 443

ZELANGA
STEEL

Carport Install
Instructions (Ground Socket)

Tools Required (Not supplied)



.Cordless drill with no.1 star bit. Socket & ring spanners 12, 16 & 17, and an 8m measuring

Components Required (Supplied)

4x	→	60mm dia. Posts with ground socket attached
1x	→	Box with nuts, bolts & tek screws
4x	→	38mm dia. Rolled diagonals with fittings
1x	→	Cross with tensioners (2 parts)
1x	→	Shade Sail

Installation

1. Mark position of poles, ensure that the diagonal measurements are correct.(7.43m)
2. Insert the ground socket using tool provided. Ensure they are plumb
3. Insert Poles and re-fit bolts through the Krinner
4. Drop one curved diagonal end into vertical post
5. Assemble Cross
6. Push one side of cross onto 38mm diagonal which is in the vertical post
7. Push next 38 dia. Into opp. Side of cross to form line of diagonal
8. Insert tek screw supplied into the side off the cross. This locks the 38 & 50 dia. Tubes to stop rotation Refer photo 2 (see *)

Installation Continued...

9. Lift other end of diagonal & place into vertical
10. Push remaining diagonals into centre cross and drop into vertical posts
11. **V.I.P. remove tek screw (*see photo 1)**
12. Fit sail to structure, ensure it is the correct way (5x5.5)
13. Move centre tensioner to its lowest position
14. Attach tensioning braces to square centre piece (see photo 2)
15. **V.I.P Install tek screws into top of each vertical to prevent roof lifting off (2 per post – see photo 4)**
16. Tension unit as per photo (see photo 2)

Zelanga Shades wish you all the best with your new carport.